

5550 WATTS

Illustrated Parts List

Questions? Help is just a moment away!

Vous avez des questions? Vous n'avez pas besoin d'aller loin pour trouver de l'aide!

Preguntas? La ayuda es justa un momento lejos!

Call: Generator Helpline

Appelez: Ligne d'assistance de Générateur

Llame: Línea Directa del Generador

1-800-743-4115 M-F 8-5 CT

BRIGGSandSTRATTON.COM

 $Model \ / \ Modèle \ / \ Modelo$ 030324




BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC JEFFERSON, WISCONSIN, U.S.A.

Manual No. 199718A Revision C (03/19/2007)



EXPLODED VIEW - MAIN UNIT



Copyright © 2007 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.



EXPLODED VIEW - PARTS LIST


Item 1	Part # J197129GS	Description KIT, Frame	Item 44	Part # 196181GS	Description ASSY., Tank, Fuel, 5 Gallon (includes
	194150GS	KIT, Vibration Mount 45°			items 41, 50, 51 & 52)
2 3	*	WASHER, M8 Lock	45	189420GS	CAP, Fuel Gauge
4	190220GS	HOUSING, Engine Adapter	48	195373GS	WIRE, Ground
	*	NUT, Hex M8 - 1.25	49	203650GS	KIT, Wheel
5 6	NSP	ASSY., Alternator (see page 5)	50	188333GS	DECAL, Fuel Tank
7	*	TPHMS, M8 - 1.25 x 35	51	194799GS	DECAL, Danger
8	96796GS	WASHER, M8 Flat	52	189235GS	DECAL, Start Instructions
9	67989GS	NUT, M8 Flange Serrated	53	192050GS	E-RING
10	190274BGS	SBHCS, 3/8-16 x 1.0 Lg	55	197798GS	DECAL, Shut-Off, Fuel
11	47480GS	HHCS, 5/16-24 x 7	56	J194907GS	HANDLE
12	*	HHCS, M8 1.25 x 25	57	189456GS	KIT, Handle Fastening
14	189009GS	BRACKET, Muffler	58	197641GS	ASSY, Control Panel
15	695398	GASKET, Exhaust	59	*	NUT, Palnut 3/16"
16	*	HCS, M6 1.0 x 12	60	189117GS	QUICK CONNECT, Fuel, 1/4 Barb
17	189008GS	MUFFLER	61	192695GS	QUICK CONNECT, Fuel, 1/4 Barb
18	*	SHCS, 5/16 - 18 x 7/8"	62	201079GS	DECAL, CO Warning
19	83083GS	SCREEN, Spark Arrest	63	189114GS	KNOB, Fuel Tank Hold Down
20	B4986GS	DECAL, Ground, Green	72	192480GS	DECAL, Warning, Fuel Line
21	194153GS	KIT, Vibration Mount			Disconnect
22	86494GS	SCREW, Wing, M6 1 x 16	900	§	ENGINE
23	195094GS	SCREW, 10-16 x .68, Self Drill			
24	192793GS	SHIELD, Heat	Parts	Not Illustrated	
25	191190GS	CAP		BB3061GS	OIL BOTTLE
26	74908GS	SCREW, M5-0.8 x 10 Taptite		197474GS	CORDSET, Storm
28	*	WASHER, Flat 1/2		MS3430	MANUAL, Engine
29	94929GS	SCREW, Hex Wash HD		199718GS	MANUAL, Operator's
30	226846	BRACKET, Oil Fill Tube		202180GS	DECAL, Family, CA EVP
31	196830GS	DECAL, Hot Muffler		186208GS	STABILIZER, 1oz Tube
34	195422GS	COVER, RBC, Plastic w/Cap		197581GS	TRAY, Overflow, Fuel
35	199838GS	KIT, Fuel Hose w/clamps (cut to fit)		198419GS	KIT, Decals Srv
37	192376GS	SCREW, 12 - 24 x 1/2 THD Forming			
40	192310GS	KIT, Vibe Mount		•	numbers are common fasteners and
41	192980GS	KIT, Valve Tank	are av	ailable at your loc	cal hardware store.

are available at your local hardware store.

^{§ -} Contact Engine Manufacturer




EXPLODED VIEW AND PARTS LIST - CONTROL PANEL



ltem	Part #	Description
1	197471GS	PANEL, Control
2	197472GS	COVER, Outlet Flip
3	188890GS	COVER, Back Panel
4	197731GS	OUTLET, 120V, 15/20A Dplx
5	189165GS	NUT, 5/32 Pal
6	197729GS	MODULE, Led
7	197958GS	SCREW, 3 x 6, Tapping
8	202030GS	BREAKER, Circuit, 20A
	191481GS	BOOT, Breaker Circuit (not shown)
9	43437GS	OUTLET, 120/240V, 30A
10	22694GS	HOUSING, Rcptcl, 6 Pin
11	82308GS	SCREW, 3 x 18, Tapping
12	192241GS	SCREW, 3.5 x 14, Tapping



EXPLODED VIEW AND PARTS LIST - ALTERNATOR



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	191043GS	ASSY, Rotor (Includes Item 12)
3	191042AGS	STATOR
4	186060GS	RBC, with 0-Ring (p/n 189197GS)
5	86308CGS	HHCS, M6 - 1.0 x 130 SEMS
6	91825GS	ASSY, Holder, Rectifier/Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll, 4mm x 10
10	193428AGS	ASSY, Wire, Ground
11	194274GS	HARNESS, Wire, Power
12	65791GS	BEARING